

ATTENTION!!! IMPORTANT PRINTING INSTRUCTIONS...

This file is intended to be printed to scale. To insure that your print is to scale, make sure "Fit to page" is *unchecked* when printing. After printing this document, accuracy can be checked by measuring the overall length and width of the template and cross-referencing these dimensions with those listed with the part.

All recoil pads are for flat butt
stocks unless otherwise noted

